# **Rapid Response**<sup>™</sup>

# **Qualitative Urine Toxicology Control**

Positive and Negative Urine Controls **REF** RR-1VPN-X.X

Product Insert

#### Instructions for Use of the Rapid Response<sup>™</sup> Qualitative Urine Toxicology Control


#### **Warnings & Precaution**

- Two amber borosilicate glass vials with silicone septa containing 10 mL of Positive Control and 10 mL of Negative Control. To avoid cross-contamination do not exchange the caps of the vials.
- The Rapid Response<sup>™</sup> Qualitative Urine Toxicology Control vials should be stored at 36-46°F (2-8°C) and returned to room temperature prior to use. The Rapid Response<sup>™</sup> Qualitative Urine Toxicology Control vials are shipped at room temperature.
- Do not freeze the control vials, repeated freezing and thawing should be avoided, as it will lead to the degradation of the controls.
- Do not use the controls beyond their expiration dates or past 31 days after opening. Controls may be employed with
  each new user, with each new lot of tests and with each new shipment of tests. The maximum number of control tests
  that can be performed with each vial is ten dip control tests per vial of negative or positive.

### **Directions for Use**

- 1. Remove the drug test from the foil pouch, and place it on a flat, dry surface.
- 2. Use the Rapid Response<sup>™</sup> Qualitative Urine Toxicology Control as you would clinical urine. Depending on the drug test format, the controls may be dipped into (strip or panel), dropped (cassette) or poured (cup).
- 3. Interpret test results at the time indicated on the relevant drug test being employed.

## **Interpretation of Results**



If problems with functioning are detected, discontinue use of the test kit immediately and contact BTNX Inc.





